

Technik



INSTALLATION AND OWNERS MANUAL

Z2402 and Z2403 VStream Replacement
Windscreen for R1200RT
Quantum® Hardcoated Polycarbonate

Attention



Special notes and cautionary measures which can prevent damage to the accessory or motorcycle.

Note:



Tips for facilitation of operation, control and adjustment, as well as maintenance work.



TOOLS REQUIRED:
Torx Wrench, T25



Right and left side of motorcycle is determined while sitting on the bike.

PARTS LIST

<u>Index</u>	<u>Description</u>	<u>Qty.</u>
1	VStream Windscreen, Quantum Hardcoated Polycarbonate	1

INSTALLATION



Retain all fasteners, as they will be reused.

1. Remove the 4 screws holding the outside plates on stock windshield. **(Torx Wrench, T25)**
2. Remove the 2 screws holding the stock windscreen to the mounts. **(Torx Wrench, T25)**
3. Place the ZTechnik VStream Windscreen into position on the stock windscreen mounts. Reinstall the original bolts through the windscreen and into the mounts. **(Torx Wrench, T25)**
4. Tighten the bolts firmly. **(Torx Wrench, T25)**
5. Reinstall the stock outside plates onto your new VStream using stock screws. **(Torx Wrench, T25)**

MAINTENANCE

Cleaning: Wash with a clean soft cloth, plenty of warm water and, if necessary, a non-abrasive soap such as dishwashing liquid. Flannel or soft chamois make good cleaning cloths.

View ZTechnik® R 1200 RT products at
www.ZTechnik.com

CARBON FIBER KITS • EXHAUST SYSTEMS • STORAGE POD
TECHMOUNT STANDS